i3right



User Manual G256

User Manual

Thankyou for purchasing the G256 iBright Classic Gamer.

PLEASE READ User Manual prior to use and keep a copy for your records.

Specifications

1. 8 Bit game console

2. Screen size: 2.8inch Full colour screen

3. Rated voltage: DC5V

4. Built in game card: 256 games

5. Charge time: ~ 2.5 Hours

6. Play time: ~ 4 hours

7. Rechargeable li-ion battery

In the Box

- 1. 1 x Classic Gamer
- 2.1x USB charge cable
- 3.1x AV cable
- 4.1x User manual

SAFETY PRECAUTIONS - IMPORTANT

BATTERY INFORMATION

- 1. This product has a rechargeable lithium battery. For your safety, please do not attempt to remove the battery. Keep product away from fire and high temperatures to avoid damage and explosion.
- 2. This product is NOT waterproof. Store product in a dry and cool environment, away from splashing water, rain, direct sunlight or humid environment.
- 3. Do not over charge the battery. Recommended charge time is 2.5 hours. Monitor charge time and disconnect product from the charger once fully charged (consider setting timers as a reminder to unplug devices).
- 4. Do not charge product on combustible materials such as beds, sofas or carpet.
- 5. Please use charge cable provided with the gamer. Do not use damaged chargers or other charging cables.
- 6. Allow time for battery to cool down after use and before recharging.
- 7. When external DC5V is used for power supply, the power supply current should be .5- 1A.
- 8. Cables, AV cords and lithium battery are included with the product.
- 9.DISPOSAL: At end of product life, DO NOT dispose lithium ion battery or product in household rubbish. Please safely dispose product as per your local council electronic and battery disposal guidelines.



WARNING! Not suitable for children under the age of 3 years.

Choking hazard - small parts.


Supervision with children recommended.



Cables and lithium battery are included with the product. Rechargeable batteries should be charged under adult supervision.

User Manual

Game Key Description



Function Description

- 1. <u>Power:</u> For portable play, please fully charge your gamer prior to use (~2.5 hours). Charge cable included in box. Power via built in rechargeable battery OR directly use adapter DC5V output to supply power (not provided). On/off button is located on top of unit.
- 2. <u>AV Output</u> Connect to TV: For play on your TV screen, connect AV cables (provided) from AV output port on your gamer to your TV.
- 3. Direction Buttons: navigate menu and game play via direction buttons.
- 4. <u>Function Buttons:</u> Due to large range of games included from different game suppliers, the function buttons vary per game. We suggest playing game a few times first to familiarise yourself with button features per game. eg. jump, shoot etc
- 5. Reset: press button to reset the screen on your gamer.
- 6. Start: after selecting your game from game menu, press start button.
- 7. <u>LED:</u> working indicator
- 8. Select: scroll through menu then push select button to choose game.
- 9. INV5V: insert charge cable to charge battery.
- 10. Volume: Control. Press up or down to increase/decrease game music.

User Manual


256 Games Card Built in

Discover 256 retro style games built into the gamer unit.

Note: Gamer is for one player only.

14+ ages - Recommended age of use. Younger users should be monitored by adults.

Enjoy your gamer. Game on!



www.iBright.com.au





Follow Us @iBrightAu

iBright Australia
Distributed by K2 Sales Pty Ltd. PO Box 696 Black Rock, VIC. 3193 Australia
e: Info@iBright.com.au