



## TWS-11 Earbuds

TRUE WIRELESS STEREO EARPHONES

### USER MANUAL

## OVERVIEW


### Choose Ear Tips



It is recommended you try middle EarTips first, it fits most people

1

(For first time pairing)



Take out both Earphones, then re-insert them into the case to activate.


Notes: If Earphones fail to charge, pls charge the case via USB cable (for details, pls follow the below steps).

## How to Pair

Put both Earphones into charging case to activate them, then take out, both Earphones will auto power on and pair with each other. After the LED for right Earphone turns blue and red, left Earphone turns blue Search T11 on mobilephone and connect it.

2

(Notes: If fail to connect, pls try the following steps by hands.)



1. Put the earphone back in the charging case to charging mode, LED solid red
2. Press and hold on both earphones for 8s, until the LED blue blinks 4 times then back to LED red
3. Take them out, two earphones will auto pair with each other

Two Earphones will auto pair with each other. When LED on right Earphone turns blue and red, left Earphone turns blue, it means both sides connected successfully

Search for T11 on mobilephone and connect it


3

## FUNCTIONS

### Power-on

Method 1: take earphones out from the charging case and they will auto power on (LED solid blue) (Make sure there is power in charging case)


Method 2: Power off earphones and hold MFB for 2s to power on (LED glows solid blue)



### Power-off

1. Put earphones back into the charging case, it will auto power off (red LED will turn on for 1s)


2. Hold MFB for 3s (red LED will turn on for 1s)



4


### Reject Call

Press and Hold MFB for 2s to reject the incoming call




### Answer Call

Press MFB to answer the incoming call and press again to end it



### Switch Audio Output


During calling, press and hold MFB for 2s to switch audio output between mobilephone and earphones



5

### Mute-on/off

During calling, double press MFB to switch mute on/off



### Play/ Pause

When listening to music, press MFB once to play / pause.



### Skip Track Forward /backward


During playing, double press MFB on right Earphone to next song, double press MFB on left Earphone to last song



6

### Voice Assistant

When standby, press and hold MFB for 2s to activate voice assistant (like Siri)



### Charge the Earphones

Insert the earphones into the charging case LED will be solid red when charging, after full charged, turn to blue for 1min, then turn off

### Charge the case

Please charge the case via USB cable, Red LED flashes when charging, turn to solid red when full charged, When low battery, blue LED flashes

7

## PRODUCT PARAMETER

Model: T11  
 Operation Range: 10m (with no obstacle)  
 Bluetooth version: V5.0  
 Charging time: approx 2hr  
 Music time: approx 5hr  
 Battery type: Li-ion  
 Bluetooth profiles: HFP/HSP/A2DP/AVRCP  
 Battery capacity (earphones): 3.7V/ 50mAH  
 Battery capacity (charging case): 3.7V/ 600mAH  
 (All technical data shall be subject to practical performance.)

Warning: Exposing your ears to loud noise over time may affect your hearing. Limit your earphone time and volume level.

## TIPS

1. Before using the Earphones, please read the manual carefully and keep it for future references..
2. The Earphones need to be fully charged prior to first-time use.
3. If the Earphones are left unused for over two weeks, please recharge it periodically.

8

4. Please use the chargers made by qualified manufacturer.
5. If the Earphones cannot be found by your phone, please check whether it is in pairing mode; if left unconnected for a long while, the Earphones will exit pairing mode, please re-enter the mode, if a procedure error of your phone occurs, reboot it; if a procedure error of the Earphones occurs, reboot or reset it.

## WARNING

1. Never disassemble or modify your Earphones for any reasons to avoid any damages and danger.
2. Do not store the Earphones in extreme temperatures (under 0 / over 45 degrees)
3. Avoid using the indicator close to the eyes of children or animals.
4. Do not use the Earphones during a thunder storm to avoid irregular function and increased risk of electric shock
5. Do not use harsh chemicals or strong detergents to clean the Earphones
6. Keep the Earphones dry.



MADE IN CHINA

9